CD-Recorder CDD2600



User's manual
 f Manuel d'utilisation
 d Benutzerhandbuch
 Gebruikershandleiding
 i Guida dell'Utente
 e Guia del usuario





CDD 2600 CD - Compact Disc Recorder

FIG.1

FRONT VIEW



REAR VIEW




FIG.1 FRONT VIEW

- 1. Headphone plug
- 2. Headphone volume control
- 3. Write indicator
- 4. Disc Trav
- 5. Disc In/Read/Error indicator
- 6. Open/Close

FIG.1 REAR VIEW

- 7. Jumperblock
- 8. Host DC power connector
- 9. SCSI connector
- 10. Audio Line Out connector

ABB.1 VORDERANSICHT d

- 1. Anschlußbuchse Kopfhörer
- 2. Lautstärke Kopfhörer
- 3. Schreibanzeige
- Schublade
 Diskette ein/Lesen/Fehler
- 6. Open/Close Taste

RÜCKANSICHT

anzeige

- 7. Jumperblock
- 8. Host Gleichstromnetzanschluß
- 9. SCSI Connector
- 10. Tonanschluß Aus-Connector

FIG.1 PARTE ANTERIORE i

- 1. Presa cuffie
- 2. Controllo volume cuffie
- 3. Indicatore di scrittura
- Cassetto del disco
- Indicatore disco inserito/Leggi/Errore
- 6. Tasto Apri/Chiudi

PARTE POSTERIORE

- 7. Blocco Jumpers
- 8. Connettore alimentazione DC
- 9. Connettore SCSI
- 10. Connettore Line Out Audio

FIG.1 PANNEAU AVANT

- 1. Prise pour casque
- Commande du volume du casque
- Témoin lumineux d'enregistrement
- Tiroir à disque
- 5. Témoin disque/lecture/erreur
- 6. Touche ouvrir/fermer

PANNEAU ARRIERE

- 7. Cavaliers
- 8. Connecteur au bloc d'alimentation C.C.hôte
- 9. Connecteur SCSI
- Connecteur de sortie de ligne audio

FIG.1 VOORKANT

- 1. Hoofdtelefoonaansluiting
- Volumeregeling hoofdtelefoon
- Schriifindicator
- 4. Disc-lade
- Disc aanwezig/lezen/ foutindicator
- 6. Openen/sluiten-toets

ACHTERKANT

- 7. Jumper-blok
- Voedingsconnector host computer
- 9. SCSI connector
- 10. Audio-connector lijnuitgang

FIG.1 VISTA FRONTAL e

- 1. Clavija de los auriculares
- 2. Control del volumen de los auriculares C.D.
- 3. Indicador de escritura
- 4. Bandeja del Disco
- Indicador de Disco introducido/Lectura/Error
- 6. Botón de Apertura/Cierre

VISTA POSTERIOR

- 7. Bloque de conectores
- 8. Conector de alimentación
- 9. Conector SCSI
- Conector de salida de Línea de Audio

WARNING

This device complies with Part 15 of the FCC (U.S.A.) Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can be used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning this equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

IMPORTANT

Any change or modifications to the equipment by the user not expressly approved by the grantee or manufacturer could void the user's authority to operate such equipment.



FOR EUROPE

"The CDD2600 is in conformity with the EMC directive and low-voltage directive."

CONTENTS

ENGLISH		
	Installation	5
FRANCAIS	3	
	Installation . Aperçu des commandes et des connexions . Utilisation et test du système d'enregistrement de disque optique . Informations supplémentaires	17 19
DEUTSCH		
	Installation . Zusammenfassung Steuereinrichtungen und Anschlüsse	31 33
NEDERLA	NDS	
	Installatie . Overzicht van bedieningsknoppen en aansluitingen . Gebruiken/testen van uw 'CD-Recordable'-systeem Aanvullende informatie	45 47
ITALIANO		
	Installazione Sommario dei controlli e dei collegamenti Funzionamento/test del vostro sistema di registrazione per CD Informazioni aggiuntive	59 61
ESPANOL		
	Instalación . Lista de controles y conexiores . Manejo/verificación de su grabador de CD . Información adicional	73 75

LASER SAFETY

This unit employs a laser. Do not remove the cover or attempt to service this device when connected due to the possibility of eye damage.

LASER-SICHERHEIT

In das Gerät ist ein Laser eingebaut. Nehmen Sie die Abdeckung nicht ab und versuchen Sie nicht, das Gerät zu reparieren, solange es angeschlossen ist. Es besteht die Gefahr einer Augenverletzung.

CAUTION

USE OF CONTROLS OR ADJUSTMENTS OR PERFORMANCE OF PROCEDURES OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARDOUS LASER RADIATION EXPOSURE.

WARNUNG

DIE VORNAHME VON REGELUNGEN ODER EINSTELLUNGEN ODER DIE DURCHFÜHRUNG VON VERFAHREN, DIE NICHT IN DIESEM DOKUMENT (DIESER BESCHREIBUNG; IM NACHSTEHENDEN TEXT) ANGEGEBEN SIND, KANN EINE GEFÄHRLICHE EINWIRKUNG VON LASERSTRAHLUNG ZUR FOLGE HABEN.

CLASS 1 LASER PRODUCT

KLASS 1 LASERAPPARAT LUOKAN I LASERLAITE

KLASSE 1 LASER-PRODUKT

CAUTION INVISIBLE LASER RADIATION WHEN OPEN AVOID EXPOSURE TO

BEAM

VARO! AVATTAESSA OLET ALTIINA NÄKYMÄTTÖMÄLLE LASER SÄTTEILYLLE

ÄLÄ KATSO SÄTEESEN

VARNING OSYNLIG LASERSTRÅLNING NÄR DENNA DEL ÄR ÖPPNAD

BETRAKTA EJ STRÅLEN

ADVERSEL USYNLIG LASERSTRÅLING VED ÅBNING. UNDGÅ UNSAETTELSE FOR

STRÅLING

DANGER INVISIBLE LASER RADIATION WHEN OPEN AVOID DIRECT

EXPOSURE TO BEAM

VORSICHT INSICHTBARE LASERSTRAHLUNG WENN ABDECKUNG GEÖFFNET

NICHT DEM STRAHL AUSSETSEN

LASER

Type Semiconductor laser GaAlAs

Wave lenght 775~795 nm (at 25° C)

Output Power 2,5 mW (Read)

35 mW (Write)

Beam divergence 60 degree.

Handling Static-Sensitive devices

This CD-Recorder drive, like all electronic equipment, is static sensitive.

Please take the proper precautions when handling the drive.

Avoid touching the SCSI connector pins as well as the audio connector pins and the jumper pins.

Keep the drive in its conductive wrapping until you are ready to install the drive in your computer.

Installing the drive

- In order to mount the drive inside your PC (or other type of computer), locate a free horizontal 5.25" bay and follow the instructions, as provided with your computer systems, for installing the drive.
- In order to prevent interference between the CD-Recorder drive and the computer, please make sure to mount the drive using all 4 mounting screws.

Safety Precautions

Europe: This drive shall be installed only with an EN60950 (IEC950) approved Power supply.

USA/Canada: This drive is for use only with IBM compatible UL listed Personal Computers or Macintosh UL listed workstations weighing less than 18 kg.

INSTALLATION

Host interface connections

Connect the internal SCSI flatcable to the SCSI interface card of your host. Connect the other end to one of the SCSI connectors at the rear of the CD-Recorder drive.

Make sure to select a free SCSI address via the jumpers on the back of the unit

Then connect the power cable in your PC to the plug on the drive (see item 8 of the rear view, fig.1).

SUMMARY OF CONTROLS AND CONNECTIONS

Front view (See flap Fig.1)

1. HEADPHONE PLUG

Connect your headphone to listen to CD-DA discs (or tracks).

2. HEADPHONE VOLUME CONTROL

Turn the wheel to the right to increase the audio volume of your headphone.

3. WRITE INDICATOR

Lights "orange" when writing of a disc occurs. Flashes "orange" during write emulation.

4. DISC TRAY

5. DISC IN/READ/ERROR indicator (dual color LED)

Lights "green" when a disc is present. Flashes "green" asymmetrically when data is being transferred from disc. Flashes "green" symmetrically when starting up a disc. Lights "red" upon error (e.g. after failed selftest).

6. OPEN/CLOSE KEY

Press the OPEN/CLOSE key to open the disc loading tray. To close the disc loading tray, push gently at the front of the tray or press the Open/Close key.

SUMMARY OF CONTROLS AND CONNECTIONS

Rear view (See flap Fig.1)

7. JUMPERBLOCK

With jumpers 1 to 3 the SCSI address is selected. Jumper 4 is for termination selection.

8. HOST DC POWER CONNECTOR (type AMP 00641737-1)

1: +12V

2: GND

3: GND

4: +5V



9. SCSI CONNECTOR (type MOLEX 70247-5005)

50 pin SCSI flatcable connector.

10. Audio line out connector (type: MOLEX 70555-0003)

1: Left

2: GND

3: GND

4: Right



Loader

11. SERVICE FLAP

For service applications only.

Not to be opened by unauthorised people without further instructions from your supplier.

OPERATING/TESTING YOUR CD-RECORDABLE SYSTEM

Copyright Statement

It is a criminal offence, under applicable copyrights laws, to make unauthorised copies of copyright-protected material, including computer programs, films, broadcasts and sound recordings. This equipment should not be used for such purposes.

Switching on

When you have successfully installed the drive and established all connections, it is now time to switch on the host.

Loading and unloading a disc

Follow the instructions below. (see Fig.1)

- 1. To open the tray: Press the Open/Close key (6).
- Load a (CD-R) disc, with the label facing upwards. The tray accommodates discs with 8 cm diameter (CD-Single) or the more usual 12 cm discs.
- 3. To close the tray, either push gently at the front of the tray or press the Open/Close key (6).

Note: for best results, use only empty discs qualified by Philips (PDO 63CDR or PDO 74CDR).

Note: don't use general purpose commercial head cleaning discs.

Switching off

Do not switch off the drive via the host after a successful write: either fixate the disc or eject it, else an incompatible disc is made.

OPERATING/TESTING

YOUR CD-RECORDABLE SYSTEM

Operating the CD-Recorder on the computer

The following lists the supported SCSI commands. An extensive description of the total command set is available on request.

MESSAGES

* Following messages are implemented in the CD-Recorder: In = Target to initiator

Code	Description Directions
00h	command complete in
02h	save data pointer in
04h	disconnect in
06h	abort out
07h	message reject in out
08h	no operation out
0Ch	bus device reset out
80h+	identify in out

Out = Initiator to target

* The following SCSI commands are implemented in the CD-Recorder: Group 0 commands:

	i
Opcode ^a	Command
00	Test Unit Ready
01	Rezero Unit
03	Request Sense
08	Read
0A	Write
0B	Seek
12	Inquiry
15	Mode Select
16	Reserve
17	Release
18	Сору
1A	Mode Sense
1B	Start / Stop Unit
1C	Receive Diagnostic Results
1D	Send Diagnostics
1E	Prevent/Allow medium removal

a. Opcode in Hexadecimal format*

OPERATING/TESTING YOUR CD-RECORDABLE SYSTEM

Group 1 & 2 - ten bytes commands :

Opcode ¹	Command
25	Read Capacity
28	Read
2A	Write
2B	Seek
2F	Verify
35	Flush Cache
3B	Write Buffer
3C	Read Buffer
42	Read Sub Channel
43	Read Disc info
45	Play Audio
47	Play Audio MSF
48	Play Audio Track / Index
4B	Pause Resume
55	Mode Select
5A	Mode Sense

* Vendor Unique commands :

Opcode ¹	Command
D1	Read Disc ID
D2	Read OPC
D3	Write OPC
E2	First Writable address
E3	Format track
E4	Reserve track
E5	Read Track Info
E6	Write Track
E7	Medium Load/Unload
E8	Finish Track
E9	Fixation (write Leadin and Leadout)
EB	Send Absorption Control Errors
EC	Recover
ED	Write
EE	Read Session Info

ADDITIONAL INFORMATION

Care of discs

Whenever a disc is not in the tray or the drive, protect it from dust, ink, or other contaminant's. Handle discs only by the outer and inner edges. When loading the disc, allow time for the door to open and then gently insert the disc.

Empty discs are separately available through your dealer.

Technical data

Performance

Capacity

120mm disc 600 Mbytes/700 Mbytes

80mm disc 200 Mbytes

Access time average 1/3 data⁽¹⁾ 325 msec. Access time max⁽¹⁾ <650 msec.

Data-transfer-rate (recording/reading)

352,8 Kbytes/sec

sustained (double speed,

mode 2 data) 176,3 Kbytes/sec

sustained (single speed,

mode 2 data)

Data-transfer-rate (read only) 1145 Kbytes/sec

(6x speed, mode 2

data)

Max. burst rate ≥ 1,4 Mbytes/sec

Interface SCSI 2

Form factor 5,25" Half Height

Data integrity from drive,

(new discs) 10⁻¹⁶

Data buffer 1Mb

Disc loading Tray (motorised)

⁽¹⁾ After spin up, including latency and command overhead, at highest speed (only valid for reading).

ADDITIONAL INFORMATION

Dimensions

 Height
 41.5 mm

 Width
 146 mm

 Depth
 206 mm

Weight max. 1 kg

Power dissipation max. 8W

Environmental

Operating temp ⁽¹⁾ 5 to 40° C Non operating temp -25 to 70° C

Reliability

MTBF (hours) 30.000 POH

Media CD-R conf. "Orange Book"

part II

Certification FCC Compliance: Class B.

UL, CSA,CEBEC.

(1) **Specifications for the "under pressure" case** (incomming air flow through the front bezel): A flow of at least 2 l/sec. of air at maximum 40°, must be realised. This will be achieved by realising at least -180 Pascal of pressure difference between inside the apparatus and outside.

Specifications for the "over pressure" case (outgoing air flow through the front bezel): A flow of at least 2 l/sec. of air at maximum 40°, must be realised. This will be achieved by realising at least +180 Pascal of pressure difference between inside the apparatus and outside. Additionally, the measured temperature of the bottom plate of the drive must not exceed 50° C.

Remark: under an environmental temperature of the drive between 5° to 30° C no airflow is necessary.

ADDITIONAL INFORMATION

Electrical interface (front of drive)

- Headphone Jack.

- RMS OUTPUT voltage: 3,1 V at 600 r.

- Signal-to-Noise Ratio: 80 dB typ. A weighted.

Electrical interface (rear of drive)

- Audio line out: RMS OUTPUT voltage 1V at 470 .

- Signal-to-Noise Ratio: 80 dB typ. A weighted.

- Data interface: 50 pin SCSI flatcable (see below).

- Power Supply:

- voltage requirements: +12V (± 5%) +5V (± 5%) - current requirements: +12V 160 mA typ.

200 mA max.

+5V 1 A typ. 1,5 A max.

Audio performance

Audio specification for line out:

	On pressed CD	On recordable CD
Output Voltage	1 V rms	1 V rms
Unbalance	max 0.25 dB	max 0.25 dB
Output Impedance	100 Ohm	100 Ohm
Amplitude Linearity	1 dB (20 Hz - 20 kHz)	2 dB (20 Hz - 16 kHz)
S/N-ratio	82 dB (87 dB A-wtg)	80 dB (85 dB A-wtg)
Total Harmonic	65 dB	55 dB
Distortion + Noise	(1kHz)	(1kHz)
Outband attenuation	min. 50 dB above 25 kHz	min. 50 dB above 25 kHz
Channel separation	min. 70 dB (20 kHz)	min. 65 dB (16 kHz)
Muting level during	min. 90 dB (BW = 20 kHz)	min. 90 dB (BW = 20 kHz)
random access		
I		

	On pressed CD	On recordable CD
Output Voltage	3.1 V rms	1 V rms
(max volume)		
Unbalance	max 0.25 dB	max 0.25 dB
Output Impedance	120 Ohm	120 Ohm
Amplitude Linearity	1.5 dB (20 Hz - 20 kHz)	1.5 dB (20 Hz - 16 kHz)
S/N-ratio	86 dB (88 dB A-wtg)	80 dB (85 dB A-wtg)
Total Harmonic	60 dB	45 dB
Distortion + Noise		
Outband attenuation	min. 50 dB above 25 kHz	min. 50 dB above 25 kHz
Channel separation	min. 67 dB (20 kHz)	min. 65 dB (16 kHz)
Muting level during	min. 90 dB (BW = 20 kHz)	min. 90 dB (BW = 20 kHz)
random access		
	l	
Note 1:		

The somewhat reduced audio quality when playing back audio tracks on CD-R discs has NO RELATION to the DIGITAL QUALITY of the audio tracks as they have been recorded onto the CD-R disc.

Note 2:


This phenomena is caused by the playback decoding electronics inside the CD-R drive, when playing audio tracks on CD-R discs (caused by different trackfollowing algorithm on the ATIP Absolute Time in Pregroove as exists only on a CD-R disc): the system will fall back to the lesser quality decoding known as 1-time oversampling. On pressed discs, the electronics uses the standard 4-times oversampling algorithm.

Note 3:

The analog output volume as specified above applies if the electronic attenuation in the playback circuitry inside the drive is non operational.

i.e. the electronic volumesetting is at

100%. However as is being recommended by the generic SCSI standard, the electronic attenuation is set to a default value of 25% at startup, meaning that only 25% of the maximum analog volume is supplied to the outputs. This attenuation can be changed by the appropriate software application.



SIGNAL	PIN NUMBER	SIGNAL	PIN NUMBER
-DB(O)	02	*TERMPWR	26
-DB(1)	04	GROUND	28
-DB(2)	06	GROUND	30
-DB(3)	80	-ATN	32
-DB(4)	10	GROUND	34
-DB(5)	12	-BSY	36
-DB(6)	14	-ACK	38
-DB(7)	16	-RST	40
-DB(P)	18	-MSG	42
GROUND	20	-SEL	44
GROUND	22	-C/D	46
GROUND	24	-REQ	48
		-I/O	50

^{*} Note: This pin provides the terminator power (plus 5 volts).

Note: All odd pins except pin 25 shall be connected to ground. Pin 25 should be left open but may be connected to ground.

Jampor Journey

JUMPERS 1 TO 3 can be used for setting SCSI addresses.

Remark: Jumper detection only by Power on or SCSI hand Reset.

Drive will always supply TERM POWER.

Drive will always generate and check parity on SCSI.

ID		0	1	2
ADDRESS	0	0	0	0
	1	1	0	0
	2	0	1	0
(DEFAULT)	3	1	1	0
	4	0	0	1
	5	1	0	1
	6	0	1	1

TERM	1 = Termination ON (DEFAULT)
	0 = Termination OFF

Auto selftest

EXECUTION

- Selftest will be activated by pushing and holding OPEN/CLOSE button for one complete Open/Close cycle of tray.
- At Host command : Send diagnostics.

VISIBLE EFFECTS

- At total selftest start:

Green, orange and red will respectively light up for about 200 msec. this will be repeated 3 times.

- At start of each individual test:
 The two LEDS will go on for 0.5 sec. and then the test starts.
- During the test:
 The two LEDS remain on
- At the end of an individual test: if the test was unsuccessful, the red error led will go on for 1 sec. If the test was successful, the green led will go on.
- At the end of the selftest:
 During 5 seconds, the orange and the green led will flash if the whole test was OK. In case of an error, the orange and the red light will flash during 5 seconds.

INDIVIDUAL TESTS

- Test internal processor RAM
- Test external SRAM
- Test EPROM
- Test DSP interface
- Test DRAM
- Test SCSI interface
- Test CDB2 interface
- Test datapath
- Test SRAM CDB2

You can reach Philips the following ways (in order of prefer-

© PHILIPS 1996

All trademarks acknowledged.